

START UP

1. FOLLOW THE ON SCREEN INSTRUCTIONS TO LOG ON TO THE COMPUTER



If computer is off, turn on using the ON button (inside the lecturn).

Computer ON button


Computer Tower

2. TURN PROJECTOR ON

Press the POWER button on the projector remote control.



LECTURN



ENDING CLASS

1. TURN THE SYSTEM OFF using the control panel

2. LOG OFF THE COMPUTER. Go to "Start" and choose "Log Off".

SWITCH DEVICES

Projecting the DVD/VCR, Computer or Document Camera

To switch between devices, USE THE BUTTONS ON THE SWITCHER INSIDE THE CABINET



VOLUME

Volume control is on the projector's remote: press the volume button, then toggle the blue lever.



Volume level is shown in the lower right of the display.

Need Help?!

HELP DESK
Dial (776)-2168

Mon. to Thurs. 7:00 am - 10:00 pm

Friday 7:00 am - 9:00 pm

Saturday 8:00 am - 5:00 pm